**Technical datasheet** 

## Flexam EX 10/2 00+A32 black AS FR /AMD

Article code: SBFL576372



General information				
Product group	Synthetic Belts			
Industry segment	Airports; Logistics: Distribution & warehousing			
Main product feature	Antistatic, Flame retardant, Low noise, Energy saving			
Indication of use	Flat, Rollers, Slider bed			
Belt construction				
Tension layer	polyester, stable			

Number of plies		2		
Top side	material	Flexam, PVC		
	finish	profile, A32 Fine rib profile		
	color	black		
Bottom side	material	Ropanol, PUR		
	finish	impregnated fabric		
	color	transparent		
Characteristics				
Food Grade (FG)	no			
Antistatic (AS)	yes	ISO 21178		

Antistatic (AS)	yes	150 21178
High conductive (HC)	no	
Flame-retardant	yes	ISO 340
ATEX approval	no	

Technical data						
Hardness	ISO 868	top side	40A	Shore		
Force at 1% elongation (static)	ISO 21181		10	N/mm	57.1	lbs/in.
Elastic modulus (k1% relaxed)	ISO 21181		6.5	N/mm	37.12	lbs/in.
Tensile strength	KV.006		150	N/mm	856.52	lbs/in.
Thickness	AB method KV.002	total	2.5	mm	0.1	in.
		top cover	1	mm	0.04	in.
Weight	AB method KV.004		2.6	kg/m²	0.53	lbs/ft²
Coefficient of friction	bottom against steel	dynamic	0.17			
		static	0.2			
	top against steel	dynamic	> 1.0			
		static	> 1.5			
Operating temperature	continuous	from / to	-15 / 80	°C	5 / 176	°F
	short	from / to	-15 / 100	°C	5 / 212	°F
Minimum pulley diameter	flexing		50	mm	1.97	in.
	backflexing		80	mm	3.15	in.
Manufacturing width	standard		2020	mm	79.53	in.
	maximum		2020	mm	79.53	in.

## Fabrication

Hot splicing is always preferable. Glueing can only be done when the belt is exposed to normal temperature and the humidity is not excessive. For the working method, consult the splice information and the equipment literature. Apply the recommended splice as indicated in the separate information.

## Additional information

This sheet contains typical values, which apply to a temperature of approx. 20 °C (68 °F), unless otherwise stated, individual data may differ.

We recommend to keep the belt tension to a practical working minimum to maximize the service life of the belt and machine parts.

Always protect belts from sunlight/UV-radiation, avoid temperatures below 10°C and above 40°C, dust and dirt. Store belts in a cool and dry place and if possible in their original packaging.

For details consult 'Storage and handling instructions' or contact our specialist.

Because of continuous development, the presented data is subject to alteration. This data replaces that included in previous publications. Ammeraal Beltech excludes any liability for the incorrect use of the above stated information. Subject to the general terms and conditions of sale and delivery, as applied by its operating companies, are all activities performed and services rendered by Ammeraal Beltech.