Technical datasheet

Flexam EX 10/2 00+05 black M2 AS FR /AMD

Article code: SBFL576361



General information					
Product group	Synthetic Belts				
Industry segment	Airports; Logistics: Distribution & warehousing				
Main product feature	Antistatic, Flame retardant, Low noise, Energy saving				
Indication of use	Flat, Rollers, Slider bed				
Belt construction					
Tension layer		polyester, stable			
Number of plies		2			
Top side	material	Flexam, PVC			
	finish	smooth, M2 Matt finish			
	color	black			
Bottom side	material	Ropanol, PUR			
	finish	impregnated fabric			
	color	transparent			
Characteristics					
Food Grade (FG)	no				
Antistatic (AS)	yes	ISO 21178			

Antistatic (AS)	yes	150 211/0
High conductive (HC)	no	
Flame-retardant	yes	ISO 340
	no	
ATEX approval	no	

Technical data						
Hardness	ISO 868	top side	80A	Shore		
Force at 1% elongation (static)	ISO 21181		10	N/mm	57.1	lbs/in.
Elastic modulus (k1% relaxed)	ISO 21181		6.5	N/mm	37.12	lbs/in.
Thickness	AB method KV.002	total	2.20	mm	0.09	in.
		top cover	0.50	mm	0.02	in.
Weight	AB method KV.004		2.6	kg/m²	0.53	lbs/ft²
Coefficient of friction	bottom against steel	dynamic	0.17			
		static	0.2			
	top against steel	dynamic	0.4			
		static	0.5			
Operating temperature	continuous	from / to	-15 / 80	°C	5 / 176	°F
	short	from / to	-15 / 100	°C	5 / 212	°F
Minimum pulley diameter	flexing		60	mm	2.36	in.
	backflexing		80	mm	3.15	in.
Manufacturing width	standard		2020	mm	79.53	in.
	maximum		2020	mm	79.53	in.

Fabrication

Hot splicing is always preferable. Glueing can only be done when the belt is exposed to normal temperature and the humidity is not excessive. For the working method, consult the splice information and the equipment literature. Apply the recommended splice as indicated in the seperate information.

Additional information

This sheet contains typical values, which apply to a temperature of approx. 20 °C (68 °F), unless otherwise stated, individual data may differ.

We recommend to keep the belt tension to a practical working minimum to maximize the service life of the belt and machine parts.

Always protect belts from sunlight/UV-radiation, avoid temperatures below 10°C and above 40°C, dust and dirt. Store belts in a cool and dry place and if possible in their original packaging.

For details consult 'Storage and handling instructions' or contact our specialist.

Because of continuous development, the presented data is subject to alteration. This data replaces that included in previous publications. Ammeraal Beltech excludes any liability for the incorrect use of the above stated information. Subject to the general terms and conditions of sale and delivery, as applied by its operating companies, are all activities performed and services rendered by Ammeraal Beltech.